



X10D COLD FUSION HAIR EXTENSION INSTALLATION

The X10D (pronounced EXTEND) Cold Fusion Hair Extension System is a revolutionary new hair extension system which does not require weaving, braiding or messy heating elements.

X10D 100% Human Hair Extensions, add length, volume & highlights to your hair & are virtually invisible. Best of all X10Ds are extremely easy to apply & last up to 6 months.

STEP 1 : CREATE A HORIZONTAL PART

To add LENGTH begin by making a horizontal part 1 to 1 1/2" above the hairline at the base of the neck.

STEP 2 : PIERCE THE X10D EXTENSION AT INNER FOLD

Carefully pierce each X10D extension at the center of the inner fold with the piercing tool provided in your startup kit.

STEP 3 : SLIDE THE CROCHET INTO THE X10D EXTENSION

Slip a 1.5mm crochet through the inner hole & place the first Extension about 1/2" from the left side hairline.

STEP 4 : PULL HAIR THROUGH THE X10D EXTENSION WITH THE CROCHET

With the crochet, pull a strand of hair into the heart of the Extension. The amount of hair pulled through, should cover 3/4 of the inner lower surface of the extension. Line up the extension with the part, & secure it to the base of the scalp.

STEP 5 : APPLY THE X10D ADHESIVE

Firmly secure the inserted strand on the lower inner surface of the extension, & apply a very thin coat of X10D ADHESIVE. Apply sparingly, while making sure to completely cover the strand as well as the full lower inner surface of the extension.

STEP 6 : JOIN THE 2 SIDES OF THE X10D EXTENSION

Join the two sides of the Twin X10D Extensions so that they meet perfectly.

STEP 7 : APPLY A CLAMP TO THE X10D EXTENSION

Apply one of the 4 clamps supplied in your Starter kit. Leave the clamp on each extension for 2-3 minutes

STEP 8: TRANSPOSE EACH CLAMP

Transpose each clamp to the most currently inserted extension, as needed, working from left to right, until the last extension in each row is completed & placed 1/2" away from the right side hairline.

SPACING BETWEEN THE EXTENSIONS

The average space between each extension should be equivalent to the width of one X10D extension. This will vary depending on the total number of extensions required to achieve the desired result.

CREATE ANOTHER PART & REPEAT STEPS 1-8

Create a second parallel horizontal part 1" to 1 1/2" above the first row & repeat steps 1 to 8 above.

INSTALLATION PATTERN

The Extensions in each consecutive row should be inserted in a checkerboard pattern when compared the row beneath it. This process should be repeated until the desired effect is reached.

TOTAL NUMBER OF ROWS

The optimal number of rows for lengthening is 5: three rows below the ears, & two above the ears, each 1" to 1 1/2" apart

TOTAL NUMBER OF X10Ds PER ROW

The average number of extensions will vary from 8-12 in the first row, 10-14 in the second row, 14-18 in the third row, & 18-24 in the 4th & 5th rows. The total number of rows will vary depending on the desired result.

Once completed, you & your customers will be totally amazed at the beauty & the elegant simplicity of the Revolutionary New X10D Cold Fusion Hair Extension System.